


Please choose the appropriate instructions for your accessory.

# Graco Inclined Sleeper Accessory Recall for Day2Dream Playard and Bedside Sleeper


**Please read completely through these directions before attempting. You may continue to use the playard, changing station and bassinet portions of the product without the Inclined Sleeper Accessory according to owner's manual.**

As part of the fulfillment process to qualify for a refund, you will need to follow these instructions to remove a portion of the accessory and return it to Graco. The U.S. Consumer Product Safety Commission (CPSC) requires that you provide proof that the accessory was rendered unusable.

## 1. Open Accessory and Cut Side Panels Out




Insert the tip of scissors into the mesh area as shown and cut along the red dashed line all the way around to remove the portion of mesh and fabric as shown, all in one piece.




When you are done, you should have 1 piece of material.

## 2. Place in Envelope



Fold the material and the form with your contact information and tuck them into the prepaid envelope you were provided. Affix the shipping label to the outside of the FedEx Envelope and take it to your nearest FedEx drop off facility. Record your FedEx tracking number from the label for future reference.

## 3. Throw Accessory Away



Please dispose of the remaining accessory by placing it in a suitable trash collection receptacle. **Do not continue to use the accessory or give it away.**

**If you have any questions about these instructions, please contact Graco's Consumer Services Team at 1-800-345-4109, Monday through Friday, 9:00am-5:00pm EST.**

**Once** Graco receives your shipment, we can move forward with processing your refund. Please note that your refund cannot be processed without first receiving the material you cut out of the accessory.

-----

**Please fill out the below contact information and place in envelope with the 1 piece of material:**

Name: \_\_\_\_\_  
 Address: \_\_\_\_\_ City: \_\_\_\_\_ State: \_\_\_\_\_ Zip code: \_\_\_\_\_  
 Phone Number: \_\_\_\_\_ Email: \_\_\_\_\_  
 Please fill in your order number \_\_\_\_\_


Please choose the appropriate instructions for your accessory.

# Graco Inclined Sleeper Accessory Recall for Rock 'n Grow Playard


Please read completely through these directions before attempting. You may continue to use the playard, changing station and bassinet portions of the product without the Inclined Sleeper Accessory according to owner's manual.

As part of the fulfillment process to qualify for a refund, you will need to follow these instructions to remove a portion of the accessory and return it to Graco. The U.S. Consumer Product Safety Commission (CPSC) requires that you provide proof that the accessory was rendered unusable.

## 1. Open Accessory and Cut the Center Section Out




Insert the tip of scissors into the fabric area as shown and cut along the red dashed line to remove the portion of fabric as shown, all in one piece.




When you are done, you should have 1 piece of material.

## 2. Place in Envelope



Fold the material and the form with your contact information and tuck them into the prepaid envelope you were provided. Affix the shipping label to the outside of the FedEx Envelope and take it to your nearest FedEx drop off facility. Record your FedEx tracking number from the label for future reference.

## 3. Throw Accessory Away



Please dispose of the remaining accessory by placing it in a suitable trash collection receptacle. **Do not continue to use the accessory or give it away.**

If you have any questions about these instructions, please contact Graco's Consumer Services Team at 1-800-345-4109, Monday through Friday, 9:00am-5:00pm EST.

**Once** Graco receives your shipment, we can move forward with processing your refund. Please note that your refund cannot be processed without first receiving the material you cut out of the accessory.

**Please fill out the below contact information and place in envelope with the 1 piece of material:**

Name: \_\_\_\_\_  
Address: \_\_\_\_\_ City: \_\_\_\_\_ State: \_\_\_\_\_ Zip code: \_\_\_\_\_  
Phone Number: \_\_\_\_\_ Email: \_\_\_\_\_  
Please fill in your order number \_\_\_\_\_


Please choose the appropriate instructions for your accessory.

# Graco Inclined Sleeper Accessory Recall for Nuzzle Nest Playard


Please read completely through these directions before attempting. You may continue to use the playard, changing station and bassinet portions of the product without the Inclined Sleeper Accessory according to owner's manual.

As part of the fulfillment process to qualify for a refund, you will need to follow these instructions to remove a portion of the accessory and return it to Graco. The U.S. Consumer Product Safety Commission (CPSC) requires that you provide proof that the accessory was rendered unusable.

## 1. Open Product and Cut the End Section Out




Insert the tip of scissors into the fabric area as shown and cut along the red dashed line to remove the portion of fabric as shown, all in one piece.




When you are done, you should have 1 piece of material.

## 2. Place in Envelope



Fold the material and the form with your contact information and tuck them into the prepaid envelope you were provided. Affix the shipping label to the outside of the FedEx Envelope and take it to your nearest FedEx drop off facility. Record your FedEx tracking number from the label for future reference.

## 3. Throw Accessory Away



Please dispose of the remaining accessory by placing it in a suitable trash collection receptacle. **Do not continue to use the accessory or give it away.**

**If you have any questions about these instructions, please contact Graco's Consumer Services Team at 1-800-345-4109, Monday through Friday, 9:00am-5:00pm EST.**

**Once** Graco receives your shipment, we can move forward with processing your refund. Please note that your refund cannot be processed without first receiving the material you cut out of the accessory.

**Please fill out the below contact information and place in envelope with the 1 piece of material:**

Name: \_\_\_\_\_

Address: \_\_\_\_\_ City: \_\_\_\_\_ State: \_\_\_\_\_ Zip code: \_\_\_\_\_

Phone Number: \_\_\_\_\_ Email: \_\_\_\_\_

Please fill in your order number \_\_\_\_\_


Please choose the appropriate instructions for your accessory.

# Graco Inclined Sleeper Accessory Recall for Everest Playard


Please read completely through these directions before attempting. You may continue to use the playard, changing station and bassinet portions of the product without the Inclined Sleeper Accessory according to owner's manual.

As part of the fulfillment process to qualify for a refund, you will need to follow these instructions to remove a portion of the accessory and return it to Graco. The U.S. Consumer Product Safety Commission (CPSC) requires that you provide proof that the accessory was rendered unusable.

## 1. Open Accessory and Cut Side Panels Out




Insert the tip of scissors into the mesh area as shown and cut along the red dashed line to remove the portion of mesh as shown, all in one piece.




Repeat for the other side. When you are done, you should have 2 pieces of material that are the same general shape.

## 2. Place in Envelope



Fold these 2 pieces of material and the form with your contact information and tuck them into the prepaid envelope you were provided. Affix the shipping label to the outside of the FedEx Envelope and take it to your nearest FedEx drop off facility. Record your FedEx tracking number from the label for future reference.

## 3. Throw Accessory Away



Please dispose of the remaining accessory by placing it in a suitable trash collection receptacle. **Do not continue to use the accessory or give it away.**

If you have any questions about these instructions, please contact Graco's Consumer Services Team at 1-800-345-4109, Monday through Friday, 9:00am-5:00pm EST.

**Once** Graco receives your shipment, we can move forward with processing your refund. Please note that your refund cannot be processed without first receiving the material you cut out of the accessory.

**Please fill out the below contact information and place in envelope with the 2 pieces of material:**

Name: \_\_\_\_\_  
Address: \_\_\_\_\_ City: \_\_\_\_\_ State: \_\_\_\_\_ Zip code: \_\_\_\_\_  
Phone Number: \_\_\_\_\_ Email: \_\_\_\_\_  
Please fill in your order number \_\_\_\_\_